



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 1501 Webster Street  
 Dayton, Ohio 45401  
 Telephone (513) 223-8161

# Operating Instructions For Model 288 AB, 265C

FIRE TRUCK, SMOKEY JOE  
ATARI

		SL2			START 2		SR2			5V		
		x			x		x					
LLP	SL1	SL5	SL3	LRP	START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x		
		SL4						SR4				
		x						x				
	SL6		SL7		COIN		SR6		SR7		POWER	
	x		x		x		x		x	x	ON	OFF
											ON	OFF

1. Insert the 288B card into program B connector, number side up.
2. Insert the 288A card into program A connector, number side up.
3. Insert the 265C card into the test fixture, number side up.
4. Insert the game board into the 265C card.
5. Slide the POWER switch to ON.
6. Push COIN or START 1 to coin the game.
7. Push SR-6 for Track Select.
8. To start the game, PUSH:

SL-2      Front or START 1  
 START-2    Back or START 2  
 SR-2      Both or START 3

9.      FRONT                      BACK

SL-1	Left	SR-1	Left
SL-3	Right	SR-3	Right
SL-5	Horn	SR-5	Bell
SL-6	Gas		

10. Push SR-7 for Slam  
 Push SL-7 for Test