

## Kurz-Kasch, Inc.

Electronics Division
Box 1246 ● 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

For Model	313ABC
	HEAD-ON

GREMLIN

**Operating Instructions** 

SL2			START 2				SR2			5V			
LLP	SL1	x SL5	SL3	LRP	×	x START1	RLP	SR1	x SR5	SR3	RRP	ON	OFF
*	×	x SL4	x	×	x	×	<b>X</b>	x	x SR4	<b>x</b>	×		
	SL6	x	SL7			COIN		SR6	x	SR7		POW	/ER
	<b>x</b>	•.	x		. A 	x	•	***		<b>x</b> .	x	ON	OFF

- 1. Insert 313B card in TF-650 "B" port, number side up.
- 2. Insert 313A card in TF-650 "A" port, number side up.
- 3. Insert 313C card in TF-650 "C" port, number side up.
- 4. Connect cables from "C" card to HEAD-ON board.

10 pin molex (5 wires) to power connector 8 pin molex (2 wires) to video connector 10 pin molex (7 wires) to P-1 connector 15 pin molex (5 wires) to coin door connector.

- 5. Turn on 5VDC and then power switch on TF-650.
- 6. Controls are as follows:

Coin - COIN SR-5 - SPEED

These are screen directions:

SR-1 - CAR LEFT SR-2 - CAR UP SR-3 - CAR RIGHT SR-4 - CAR DOWN

- 7. Switch on "A card" (advert) is the advertising switch-This should be in OFF position for test.
- 8. The COIN LED on "A card" should FLASH each time "COIN" on TF-650 is pushed.